


ROUTING INSTRUCTIONS:

1. PREPARE INSIDE FACE (PANIC SIDE) OF ACTIVE STILE PER VIEW #1 & TEMPLATE 10-694.
2. PREPARE INSIDE FACE (PANIC SIDE) OF HINGE STILE PER VIEW #2 & TABLE "A".
3. PREPARE THRESHOLD PER VIEW #3.
4. PREPARE HEADER PER VIEW #4.
5. IF LOCK CYLINDER IS BEING USED SEE DWG. 10-783-1/10-783-2 AND TEMPLATE 10-695 FOR DOOR PREP. & INSTALLATION.
6. FOR MOUNTING & ADJUSTMENTS OF THE 2085B SEE OPPOSITE SIDE THIS PAGE.
(DWG. 10-808 SHEET 2 OF 2)

DIMENSIONAL TOLERANCES UNLESS OTHERWISE SPECIFIED	APPROVALS	DATE	 Jackson EXIT DEVICE <small>3447 UNION PACIFIC AVE. LOS ANGELES, CALIF. 90033</small>
DECIMAL DIMENSIONS .XX ± .010	APPROVED		
DECIMAL DIMENSIONS .XXX ± .005	CHECKED		
ANGULAR ± ° FRACTIONAL ± 1/64	DRAWN	R.M. 4/7/94	
MATERIAL	SCALE	NONE	
NEXT ASSY. 2085B-KITS	FINISH	ROUTING INSTRUCTIONS	
QTY. USED 1	HEAT TREAT	2085B PANIC DEVICE	
		SHEET 1 OF 2 SHEETS DWG. NO. 10-808 REV.	